

Robostar Robot
N1 Series Option
C-net



- | Option Module
- C-net

Robostar
www.robostar.co.kr

ROBOSTAR ROBOT
N1 Series Option
C-net



- | Option Module
- C-net

Robostar
www.robostar.co.kr

Copyright © ROBOSTAR Co., Ltd 2012

The copyright of this user manual is owned by Robostar Co., Ltd. No part of this manual may be used in any form or by any means without Robostar Co., Ltd. Specifications are subject to change without prior notice.

Regarding Product Warranty

Robostar products are manufactured under strict quality control and all Robostar products are covered under one year warranty from the date of manufacture. We offer free services during this warranty period only for mechanical breakdowns caused by faults by Robostar or breakdowns which arise from problem in design and manufacturing faults during normal use.

No free service is provided to the following occasions.

- (1) After the warranty period expires
- (2) Mechanical troubles caused by inappropriate repairs, alteration, movement and other negligent handling directed by your company or a third party.
- (3) Mechanical troubles caused by use of other products than the ones assigned by our company, such as components and grease
- (4) Mechanical troubles caused by fires, disasters, earthquakes, storm and flooding and other natural disasters
- (5) Malfunction due to use in environment beyond our product specifications, such as in excretions and flooding
- (6) Malfunction due to normal wear of consumable parts
- (7) Malfunction due to lack of carrying out maintenance work checklist as listed in User Manual and Handling Manual
- (8) Damage not included in robot repair costs

Address and Contact Details for Robostar Co., Ltd

- Head Office and Factory
700, Suin-ro, Sangnok-gu,
Ansan-City, Gyeonggi-do, Republic of
South Korea (426-220)
- 2nd Factory
108, Saneop-ro, Gwonseon-gu,
Suwon-City, Gyeonggi-do, Republic of
South Korea (441-813)

- Service Inquiry and Product Inquiry
 - Sales Inquiry
TEL. 031-400-3600
FAX. 031-419-4249
 - Customer Inquiry
TEL. 1588-4428



www.robostar.co.kr

Composition of User Manual

The User Manual of this product is composed of the following. If this is the first time to use this product, fully understand each and every detail in the manual before use.

- **C-net**

Explains how to connect a N1 series connector using a C-net as well as how to use it.

Table of Contents

CHAPTER 1. OVERVIEW	1-1
1.1 SYSTEM CONFIGURATION	1-1
CHAPTER 2. FUNCTION	2-1
2.1 RS-232 COMMUNICATION	2-1
2.2 D-SUB 9PIN CONNECTOR	2-1
CHAPTER 3. INSTALLATION AND OPERATION SETTING.....	3-1
3.1 HOW TO INSTALL HARDWARE.....	3-1
3.2 HOW TO CONNECT CABLE	3-1
3.3 CONTROLLER SETTING	3-2
3.3.1 RS-232C Communication Setting.....	3-2
CHAPTER 4. EXAMPLES OF C-NET SETTING ON TOUCH PANEL	4-1
4.1 EXECUTING EASYBUILDER8000 PROGRAM.....	4-1
4.2 ADD NEW	4-2
4.3 SYSTEM PARAMETER SETTING.....	4-3
CHAPTER 5. MEMORY MAPPING.....	5-1
5.1 N1 CONTROLLER DATA MAPPING.....	5-1
5.1.1 N1 Series System Input #1.....	5-2
5.1.2 N1 Series System Input #2 & FIELDBUS INPUT#1.....	5-3
5.1.3 N1 Series FIELDBUS INPUT #2	5-3
5.1.4 N1 Series System Output #1	5-3
5.1.5 N1 Series FIELDBUS Output #2	5-4
5.2 PRECAUTION FOR USE IN N1 SERIES SYSTEM MODE	5-4

Chapter 1. Overview

1.1 System Configuration

N1 controller makes use of C-net protocols to enable communication with such systems as PC or PLC. C-net protocol communication becomes possible through the use of Host Port on Main Board of N1 controller.




Fig. 1.1 C-net System Configuration

※ N1 controller supports C-net protocols for "Master-K"/"GLOFA" series.

Chapter 2. Function

2.1 RS-232 Communication

RS232C communication distance is generally 15m, but the greater the communication speed gets, the shorter the distance becomes.





Fig. 2.1 Asynchronous Communications Format

- Start bit : Indicates the start of communications Format
- DATA bit : Configurable in bit sizes 5/6/7/8, indicating communication data value with LSB first
- Parity bit : Configurable to No/Even/Odd and detectable when 1 bit is changed by noise
- Stop bit: Configurable in sizes 1/1.5/2, indicating the end of data

2.2 D-SUB 9Pin Connector



	Description
TXD	Transmit Data, communication data output signal
RXD	Receive Data, communication data input signal
RTS	Used for Ready To Send modem communication, displaying communication preparation status and applicable as a general-purpose output port
CTS	Used for Clear To Send modem communication, displaying communication preparation status and applicable as a general-purpose input port
DTR	Signals for preparing Data Terminal Ready modem communication, applicable as an output port
DSR	Signals for preparing Data Set Ready modem communication, applicable as an input port
DCD	Data Carrier Detect, input port
RI	Ring Indicator input port
GND	Ground

Table 2.1 Description of Connector

Chapter 3. Installation and Operation Setting

3.1 How to Install Hardware

Take the following procedure and you can use C-net protocols of N1 series controller.

- 1) Connect a Serial cable to N1 to communication port (HOST PORT) on controller's Main Board.




Fig. 3.1 How to Connect Serial Cable

3.2 How to Connect Cable

For how to connect cable, refer to Fig. "3.2 Cable Wiring Diagram".




Fig. 3.2 Cable Wiring Diagram

Pin No.	Name	Content	Description of Functions
2	RXD	Received Data	Receive Data Signal
3	TXD	Transmit Data	Transmit Data Signal
5	GND	Ground	Ground

Table 3.1 Description of Wiring Pin Numbers

3.3 Controller Setting

To use C-net protocols in N1 series controller, you should set RS-232C communication. Default value for baud rate is set to 115,200bps.

3.3.1 RS-232C Communication Setting

1. Setup Procedure

Step 1.

Move to PARA screen

```

<MAIN MENU>
1. JOB          2. RUN
3. HOST         4. PARA
5. ORIGIN      6. I/O
7. SYSTEM      8. GPNT
9. INT/FLT     A. ALARM

                SELECT #
    
```

4
L

Open initial menu screen

Select 4: PARA

```

<PARAMETER>
NO              TYPE
*CH1           XYZW
CH2            XY_TEST

SEL  INFO  PUB  EXIT
    
```

F3

Open PUBLIC PARAMETER group screen

```

<PUBLIC PARAMETER>
1: HW CONF    2: PALLET
3: PLC         4: ETC

                group #
    
```

1
Q

Select 1:HW CONF

Step 2.

Move to COMM screen

```

<PUBLIC-HW CONF(0)>
1: TMR          2: COMM
3: I/O         4: D-MAN
5: SVON        6: A I/O

                item #
    
```

2
R

Select 2: COMM

Step 3.

RS232C setup screen

```
<HW CONF - COM>
  COMMUNICATION SET
  1: COM PORT SET
  2: FIELD BUS

group #
```

Select 1: RS232C



```
<COM - PORT SET 1/2>
  PORT:HOST
  PROTOCOL:  N1
  BAUD RATE: 230400
  SEPARATOR: CR+LF
  ID:         0

HOST RS485
```

Set C-Net protocol



```
<COM - PORT SET 2/2>
  PORT:HOST
  LENGTH:    8 bits
  STOP BIT:  1 bits
  PARITY:    disable
  FLOW:      NONE

HOST RS485
```

Set C-Net protocol

Item	Set Value	Default Value
PROTOCOL	C-Net	N1
BAUD RATE	115,200	115200
LENGTH	8	8
STOP BIT	1	1
PARITY	disable	disable
FLOW	NONE	NONE
ID	0	0

※ ID currently supports no functions.

Chapter 4. Examples of C-net Setting on Touch Panel

This Manual uses the Easyview model MT8056T supporting "Master-K" and "GLOFA" C-net. (Also available for use are other Touch Panel products supporting "Master-K" and "GLOFA" C-net.) For how to set C-net communication of model MT8056T, EasyBuilder8000 program provided by Easyview was adopted for use.

4.1 Executing EasyBuilder8000 Program

Execute EasyBuilder8000 and a window comes up as shown in Fig. 4.1 below.




Fig. 4.1 Screen executing Easybuilder8000

4.2 Add New

Select File->New from menu.




Fig. 4.2 Create Project

Select MT8056T from Model. (The product described in this Manual is a model MT8056T.)




Fig. 4.3 Product Selection Screen

Click OK button and a window comes up as shown in Fig. 4.4.

4.3 System Parameter Setting

Click New... button at the center of the window.




Fig. 4.4 Parameter Setting

Select PLC from the combo box at top of "Fig. 4.5".

Device Properties

Name : Mitsubishi FX0s/FX0n/FX1s/FX1n/FX2

HMI PLC

Location : Local Settings ...

PLC type : Mitsubishi FX0s/FX0n/FX1s/FX1n/FX2
V.1.20, MITSUBISHI_FX0N.so

PLC I/F : RS-485 4W

COM : COM1 (9600,E,7,1) Settings...

PLC default station no. : 0

Default station no. use station no. variable

Use broadcast command

Interval of block pack (words) : 5

Max. read-command size (words) : 32

Max. write-command size (words) : 32

OK Cancel

Fig. 4.5 Device Setting

Next, select PLC type and a "Fig. 4.6" window comes up.

Select LS industrial System.




Fig. 4.6 Product Group Selection Screen




Fig. 4.7 Select PLC Type

For Device, select Master-K C-net or Glofa C-net.

CAUTION

- C-net protocols supported from N1 controller support "MASTER-K", "GLOFA" series ONLY.

Set COM PORT.

The image shows a 'Device Properties' dialog box for a device named 'LS MASTER-K Cnet'. The dialog is divided into several sections. At the top, the 'Name' field contains 'LS MASTER-K Cnet'. Below this, there are radio buttons for 'HMI' and 'PLC', with 'PLC' selected. The 'Location' is set to 'Local' with a 'Settings ...' button next to it. The 'PLC type' is 'LS MASTER-K Cnet' with a version 'V.1.10, LS_MASTER_K_CNET.so'. The 'PLC I/F' is 'RS-232'. The 'COM' field is 'COM1 (38400,N,8,1)' and the 'Settings...' button next to it is highlighted with a red box. Below the 'COM' field, there is a 'PLC default station no.' field set to '0', and two checkboxes: 'Default station no. use station no. variable' and 'Use broadcast command', both of which are unchecked. At the bottom, there are three dropdown menus: 'Interval of block pack (words)' set to '5', 'Max. read-command size (words)' set to '32', and 'Max. write-command size (words)' set to '32'. At the very bottom of the dialog are 'OK' and 'Cancel' buttons.

Fig. 4.8 Device Setting

Click Settings.... in "Fig. 4.8".




Fig. 4.9 COM PORT Setting

Set the communication speed with RS-232 communication PORT.

CAUTION

➤ For settings related to N1 controller communications, refer to "3.3 Controller Setting"




Fig. 4.10 System Parameter

Fig. 4.10 shows a window where System Parameter setup is complete for C-net protocols to be used.

Chapter 5. Memory Mapping

5.1 N1 Controller Data Mapping

Controller Data Mapping					
Data	Description		Data	Description	
M0.0~0.F	IN	System Input #1	M10.0~10.F	OUT	System Output #1
M1.0~1.F	IN	User Input	M11.0~11.F	OUT	User Output
M2.0~2.F	IN	Option Input 0	M12.0~12.F	OUT	Option Output 0
M3.0~3.F	IN	System Input #2	M13.0~13.F	OUT	Error Code Read
	IN	FieldBus Input #1			
M4.0~4.F	IN	Option Input 1	M14.0~14.F	OUT	Option Output 1
M5.0~5.F	IN	Option Input 2	M15.0~15.F	OUT	Option Output 2
M6.0~6.F	IN	Option Input 3	M16.0~16.F	OUT	Option Output 3
M7.0~7.F	IN	FieldBus Input #2	M17.0~17.F	OUT	FieldBus Output #1
D0	IN/OUT	Global Point Data X(A)	D80	OUT	Current Position X(A)
D2	IN/OUT	Global Point Data Y(B)	D82	OUT	Current Position Y(B)
D4	IN/OUT	Global Point Data Z	D84	OUT	Current Position Z
D6	IN/OUT	Global Point Data W	D86	OUT	Current Position W
D8	IN/OUT	Global Integer Input	D88	OUT	ERROR CODE
D9	IN	Global Integer Index	D89	OUT	AUTO VEL
D10	IN	JOG VEL Rate Input	D90	IN	RESERVED
D11	IN	Global Point Index	D91	OUT	Info Data 1 Output
D12	IN	Pull Up Value Input	D92	OUT	Info Data 2 Output
D13	IN/OUT	Global Float Input	D93	OUT	Info Data 3 Output
			D94	OUT	Info Data 4 Output
D15	IN	Global Float Index	D95	OUT	Running JOB Number

Note) When using Option I/O, change Parameter I/O EXT B/D value to 2.

(Refer to Handling Manual "1.3.1.3 Extension I/O Board Setting".)

Note) JOG Velocity Rate Input in D10 applies in JOG Mode whose setup range is 1~100%. The values set are converted to percentage per axis based on Jv value for JOINT MOTION parameters.

5.1.1 N1 Series System Input #1

N1 series holds the System Bits commonly used between Robot Channel 1 and 2, and these common Bits operate differently between channels depending on CH_SEL Bit settings.

When the set value for CH_SEL Bit is Low, it corresponds to Robot Channel 1, with High corresponding to Robot Channel 2.

System Input #1 (M0.0 ~ M0.F)			
0	CH SEL	8	MODE 1 / AXIS 1
1	PROG 0	9	MODE SEL
2	PROG 1	A	JOG VEL
3	PROG 2	B	VEL+ / MOV+
4	PROG 3	C	VEL- / MOV-
5	PROG 4	D	REBOOT
6	PROG SEL	E	ORG #1
7	MODE 0 / AXIS 0	F	START #1

Commonly-used bits are PROG_0 ~ PROG_4, PROG_SEL, MODE0/AXIS0, MODE1/AXIS1, MODE SEL, JOG VEL, VEL+/MOV+, and VEL-/MOV-. When using the common Bit, check the set value for CH_SEL Bit. If the set value for CH_SEL Bit is not correct, an unwanted robot channel may operate. The FieldBus timing diagram represented in this Manual is examples for Channel 1, and for handling and operating Channel 2, change the set value for CH_SEL Bit to High in Channel 1 timing diagram. Reading and writing Global Integer and Global Float Data can be used regardless of CH_SEL Bit setup.

CAUTION

- For description of the functions of each Bit, refer to Handling Manual “3.3.4 System Input/Output Functions”.

5.1.2 N1 Series System Input #2 & FIELDBUS INPUT#1

System Input #2 (M3.0 ~ M3.7)		FieldBus Input #1 (M3.8 ~ M3.F)	
0	STOP #1	8	DATA TYPE: XY좌표
1	Reserved	9	DATA TYPE: Angle 좌표
2	SERVO ON #1	A	Data Type: Pulse (Read Only)
3	ORG #2	B	Mode Select (/Current OR GPNT)
4	START #2	C	Write Enable Flag(Position,GINT)
5	STOP #2	D	READ Enable Flag(Position, GINT)
6	Reserved	E	Reserved
7	SERVO ON #2	F	Reserved

5.1.3 N1 Series FIELDBUS INPUT #2

FieldBus Input #2 (M7.0 ~ M0.F)			
0	JOG A(X)+	8	AUTO RUN MODE
1	JOG A(X)-	9	STEP RUN MODE
2	JOG B(Y)+	A	JOG MODE
3	JOG B(Y)-	B	JOG Forward SEL
4	JOG Z+	C	Reserved
5	JOG Z-	D	Reserved
6	JOG W+	E	Info Data Mode SEL #0
7	JOG W-	F	Info Data Mode SEL #1

5.1.4 N1 Series System Output #1

System Output #1 (M10.0 ~ M10.F)			
0	CH SEL	8	ORG OK #2
1	ALL ALARM	9	RUNNING #2
2	READY #1	A	INPOS/INRNG #2
3	ORG OK #1	B	SERVO ON #2
4	RUNNING #1	C	Reserved
5	INPOS/INRNG #1	D	Reserved
6	SERVO ON #1	E	Reserved
7	READY #2	F	Reserved

5.1.5 N1 Series FIELDBUS Output #2

FieldBus Output #1 (M17.0 ~ M17.F)			
0	Write Complete Flag	8	Auto Run Mode DIS
1	Read Complete Flag	9	Step Run Mode DIS
2	Reserved	A	JOG Mode DIS
3	Forward Moving State DIS	B	Reserved
4	Reserved	C	Info Data Mode SEL #0
5	Brake State DIS	D	Info Data Mode SEL #1
6	Reserved	E	Reserved
7	Reserved	F	Reserved

5.2 Precaution for Use in N1 Series System Mode

1. < Precautions for Use in Auto Mode >

- ① GINT, GFLOAT and GPNT commonly use Read / Write Enable Flag so the Index value of an unused variable is allocated at a time no change is intended.
- ② Coordinate Write functions, among Data Types, allow XYZW and ABZW ONLY to be available for use.
- ③ Only PROGRAM NUM entered from SYSTEM MODE is sent out.
- ④ VEL output enables sending out robot's travel speed in JOG MODE and AUTO MODE.

2. < Precautions for Use in JOG Mode >

- ① JOG_VEL input is applicable only in JOG MODE and when the value is 0 it operates at 1% speed.
- ② VEL output enables sending out robot's travel speed in JOG MODE and AUTO MODE.
- ③ AUTO RUN MODE, STEP RUN MODE and JOG MODE in Field Bus Input #2 should be entered by pulse input. (When each mode is set to High, the Bit selected on Jog axis in FieldBus Input #2 operates in an abnormal manner.)

Rev.	Date of Revision	Content	Modifier	S/W Version
V.1	2012.12.31	First Edition Print		

N1 ROBOT CONTROLLER

CONTROLLER MANUAL

FIRST EDITION DECEMBER 2012

ROBOSTAR CO, LTD

ROBOT R&D CENTER
