



Robostar Robot

RcT Series Alarm Code Manual (RcT-1.01.07)



- Controller Manual
- Operation Manual
- Programming Manual
- Unihost Manual
- Alarm Code Manual



The copyright of this instruction manual belongs to Robostar Co., Ltd. No part of this manual can be used in any form or by any means without the permission of Robostar Co., Ltd.

Specifications are subject to change without prior notice.

About Warranty

The products of Robostar are manufactured under thorough quality control, and the term of guarantee of all products of Robostar is one year from production date. Only for machine failure due to Robostar's fault or failure occurred due to design and production during normal use within the term of guarantee, Robostar will provide after sales service free of charge.

The following cases will be excluded from the after sales service free of charge.

- (1) After expiration of the term of guarantee
- (2) Failure due to improper repair, remodeling, moving, or mishandling directed by your company or the third party
- (3) Failure due to use of parts, grease or others not designated by Robostar
- (4) Failure due to fire, disaster, earthquake, storm & flood, or other natural calamity
- (5) Failure due to using of the product in the environment not stipulated in product specification of Robostar
- (6) Failure due to using up of consumable parts
- (7) Failure occurred by not observing maintenance details stipulated in the instruction manual
- (8) Loss or damage excepting the cost for robot repair

Address and Contact Points

- HQ and factory
700, Suin-ro, Sangnok-gu,
Ansan-City, Gyeonggi-do, Republic of
South Korea (426-220)
- Factory 2
108, Saneop-ro, Gwonseon-gu,
Suwon-City, Gyeonggi-do, Republic of
South Korea (441-813)
- Service request & inquiry
 - Sales inquiry
TEL. 031-400-3600
FAX. 031-419-4249
 - Customer inquiry
TEL. 1588-4428



www.robostar.co.kr

Configuration of Instruction Manual

The instruction manual of this product consists of the following. The first user of this product must be well aware of all contents of this manual before use.

- **Controller Manual**

Describes general details of the controller such as controller overview, installation and how to interface with an external device.

- **Operation Manual**

Describes overall methods of controller use as well as parameter setup, JOB program editing and robot operation.

- **Programming Manual**

Describes a Robostar robot program, RRL (Robostar Robot Language), and how to write robot program by RRL.

- **Unihost Manual**

Describes 'Unihost' that is a Robostar online PC program.

- **Alarm Code Manual**

Describes alarm code.

- **Additional Function Manual**

Describes additional functions of the relevant firmware version.

Manual Configuration

The manual consists of the followings.


- **Chapter 1 Configuration of controller alarm code**
Describes many alarms occurs while using the controller

- **Chapter 2 Controller alarm code table**
Describes alarm code details displayed on the Pendant and measures

Robostar

Table of Contents

- CONFIGURATION OF CONTROLLER ALARM CODE..... 1
- CONTROLLER ALARM CODE TABLE..... 1
 - FILE SYSTEM 1
 - DEVICE..... 2
 - PROTECTION 3
 - RUN TIME..... 5
 - COMPILE 6
 - TRAJECTORY 7
 - EMERGENCY..... 9
 - SERVO DRIVER..... 12
 - ETHERCAT 21
- REVISION..... 1



Overview

➤ Configuration of controller alarm code

- Describes many alarms which can occur while using the controller.
- **Alarm Code Display**
Displays 'alarm code' on the teaching pendant screen when controller alarm occurs.
- **Alarm Message Display**
Displays details of 'alarm message' displayed on the teaching pendant.
- **Secondary type message**

Type	Detail	Example
ROBOT: @ AXIS: ⑥	Alarm occurred on ⑥ axis of No @ robot	ROBOT:1: AXIS:1 alarm occurred on No 1 axis of No 1 robot

※ There can be no secondary message according to alarm state.

- **Alarm Level Display**

Level	Detail
1	Alarm which released by Reset key after taking measures against alarm
2	Alarm which needs power re-input
3	Alarm which needs replacement of device

➤ Controller Alarm Code Table

- Describes alarm code detail displayed on the Pendant and measures
 - File System (1001~)
 - Device (1051~)
 - Protection (1101~)
 - Run Time (1201~)
 - Compile (1301~)
 - Trajectory (1401~)
 - Emergency (2101~)
 - Servo Driver (4001~)
 - EtherCAT Communication (4501~)

■ File System

Code	1003	Message	Out of Memory		
Description	Prevention of memory allocation error			Level	2
Cause			Measures		
<p>■ Memory allocation failed in the program inside the controller.</p>			<p>■ Check alarm release after turning controller power OFF => ON</p> <p>- In case of continuous occurrence,</p> <ol style="list-style-type: none"> 1. Reinstall RAM on the motherboard 2. Replace RAM on the motherboard 		
Code	1021	Message	Job step info error		
Description				Level	1
Cause			Measures		
<p>■ Actual JOB step differs from recorded JOB step when it is loaded to the memory to execute JOB.</p>			<p>■ Press "RST" button to release the alarm.</p> <p>■ Re-write JOB after checking JOB step at which error occurs.</p>		



■ Device

Code	1073	Message	Ext-IO Protocol err	
Description	EXT- DIO board communication error		Level	1
Cause		Measures		
<p>■ Data received onto the EXT-DIO board are not correct.</p>		<p>■ Press "RST" button to release the alarm.</p> <p>- In case of continuous occurrence,</p> <ol style="list-style-type: none"> 1. Check installation status of EXT-DIO, DIO board and harness. 2. Replace EXT-DIO board. 		
Code	1074	Message	Extend IO Data error	
Description	EXT- DIO board communication Data error		Level	1
Cause		Measures		
<p>■ Output data transmitted from the controller differs from output data transmitted from EXT-D IO.</p>		<p>■ Press "RST" button to release the alarm.</p> <p>- In case of continuous occurrence,</p> <ol style="list-style-type: none"> 1. Check harness connected to EXT-DIO board and DIO board; 2. Replace EXT-DIO board. 		
Code	1075	Message	Extend IO Fuse error	
Description	EXT-DIO over current protection		Level	3
Cause		Measures		
<p>■ Occurs when FUSE on the EXT-DIO board blows.</p>		<p>■ Replace Fuse on the EXT-DIO board.</p> <p>- In case of continuous occurrence,</p> <ol style="list-style-type: none"> 1. Check device and harness connected to EXT-DIO board. 		
Code	1091	Message	FAN error	
Description	FAN error		Level	1
Cause		Measures		
<p>■ FAN error</p> <p>■ FAN cable error</p>		<p>■ Press "RST" button to release the alarm.</p> <p>- In case of continuous occurrence,</p> <ol style="list-style-type: none"> 1. Check THE FAN 2. Check state of FAN Connector contact on the Safety Board. 3. REPLACE THE FAN 		

■ Protection

Code	1177	Message	MC ON error		
Description	MC (Magnetic Contact) contact state error			Level	1
Cause			Measures		
<p>■ Occurs when MC contacts (ON) when the controller is in emergency stop state. (MC must be OFF in alarm state.)</p>			<p>■ Press "RST" button to release the alarm. - In case of continuous occurrence, 1. Check MC wiring cable 2. Replace THE MC. 3. Replace the Safety board.</p>		
Code	1178	Message	MC OFF error		
Description	MC (Magnetic Contact) contact state error			Level	1
Cause			Measures		
<p>■ Occurs when MC contacts (ON) when the controller is in emergency stop state. (MC must be OFF in alarm state.)</p>			<p>■ Press "RST" button to release the alarm. - In case of continuous occurrence, 1. Check MC wiring cable. 2. Replace THE MC. 3. Replace the Safety board.</p>		
Code	1184	Message	H/W P-Limit error	ROBOT: ①	AXIS: ②
Description	Limit sensor detection			Level	1
Cause			Measures		
<p>■ Limit sensor is detected.</p>			<p>■ Move robot position to avoid detection of Limit sensor and press "RST" button to release the alarm. - In case of continuous occurrence, 1. Check wiring cable and DIO board of the Limit sensor. 2. Replace sensor.</p>		
Code	1185	Message	H/W N-Limit error	ROBOT: ①	AXIS: ②
Description	Limit sensor detection			Level	1
Cause			Measures		
<p>■ Limit sensor is detected.</p>			<p>■ Move robot position to avoid detection of Limit sensor and press "RST" button to release the alarm. - In case of continuous occurrence, 1. Check wiring cable and DIO board of the Limit sensor. 2. Replace sensor.</p>		
Code	1186	Message	In range error	ROBOT: ①	AXIS: ②
Description	IN RANGE EXCESS			Level	1

Cause	Measures
<ul style="list-style-type: none"> ■ Axis position exceeded IN RANGE setting range. 	<ul style="list-style-type: none"> ■ Check if current robot position is within INRANGE range and move to satisfy allowable range. ■ Press "RST" button to release the alarm. ■ Adjust teaching point of the relevant axis. ■ Adjust IN RANGE.

Code	1187	Message	Use range error	ROBOT: Ⓐ AXIS: Ⓑ
Description	USE RANGE EXCESS			Level
				1

Cause	Measures
<ul style="list-style-type: none"> ■ USE RNAGE setting range is exceeded when USE RANGE is used. 	<ul style="list-style-type: none"> ■ Check if current robot position is within INRANGE range and move to satisfy allowable range. ■ Press "RST" button to release the alarm. ■ Adjust teaching point of the relevant axis. ■ Adjust IN RANGE. ■ Adjust USE RANGE.



■ Run Time

Code	1204	Message	Not Teaching Point	ROBOT: ①
Description	Use of point for which teaching is not conducted			Level 1
Cause		Measures		
<ul style="list-style-type: none"> Point for which teaching is not conducted is used during use of robot move related command. 		<ul style="list-style-type: none"> Press "RST" button to release the alarm. Check use of point for which teaching is not conducted or teaching state of used point in JOB program. Conduct point teaching referring to the operation manual. 		
Code	1219	Message	Range Over error	ROBOT: ① AXIS: ②
Description	Teaching point exceeded allowable range			Level 1
Cause		Measures		
<ul style="list-style-type: none"> Value of point for which teaching is conducted got away from the setting range System parameter (RANGE) setting is not proper. 		<ul style="list-style-type: none"> Press "RST" button to release the alarm. Check if value of point for which teaching is conducted is within the setting range. Correct system parameter (RANGE). 		
Code	1236	Message	Interpreter error	
Description	JOB program execution error			Level 1
Cause		Measures		
<ul style="list-style-type: none"> Controller can't understand while running robot command program or wrong operation is tried to be operated. 		<ul style="list-style-type: none"> Press "RST" button to release the alarm. Check Line Number and detailed message to take measure and then retry. 		

■ **Compile**

Code	1315	Message	Compile error		
Description	JOB program Compile error			Level	1
Cause			Measures		
<ul style="list-style-type: none"> ■ The controller can't understand robot command program written by a user or writing of command program is wrong. 			<ul style="list-style-type: none"> ■ Press "RST" button to release the alarm. ■ Check Line Number and detailed message to take measure and then retry. 		



■ Trajectory

Code	1422	Message	Time Sched. Error	ROBOT: ① AXIS: ②
Description	Failure of motion command time schedule			Level 1
Cause		Measures		
<ul style="list-style-type: none"> ■ PTP motion (JMOV) Time Schedule failed. 		<ul style="list-style-type: none"> ■ Check Motion Parameter. ■ If VEL, ACC command is used, check setting value. ■ Press "RST" button to release the alarm. 		
Code	1423	Message	Over Range Error	ROBOT: ① AXIS: ②
Description	position command exceeded RANG (SW-Limit) setting range			Level 1
Cause		Measures		
<ul style="list-style-type: none"> ■ Axis move position exceeded allowable range. ■ Teaching point is within allowable range, but moving path exceeded allowable range. 		<ul style="list-style-type: none"> ■ Check if current robot position is within allowable range. If it exceeded allowable range, move to satisfy allowable range. ■ Press "RST" button to release the alarm. ■ Adjust teaching point of the relevant axis ■ If FOS command is used, lower FOS setting value. 		
Code	1424	Message	Over Velocity Error	ROBOT: ① AXIS: ②
Description	Allowable velocity command range is exceeded			Level 1
Cause		Measures		
<ul style="list-style-type: none"> ■ Moving velocity of axis exceeded allowable range. ■ Velocity of Linear motion is within allowable range, but moving velocity of each axis exceeded allowable range. 		<ul style="list-style-type: none"> ■ Adjust velocity setting of the relevant axis. ■ Press "RST" button to release the alarm. 		
Code	1425	Message	Over Accel Error	ROBOT: ① AXIS: ②
Description	allowable acceleration command range is exceeded			Level 1
Cause		Measures		
<ul style="list-style-type: none"> ■ Moving acceleration of axis exceeded allowable range. ■ Acceleration of Linear motion is within allowable range, but moving acceleration of each axis exceeded allowable range. 		<ul style="list-style-type: none"> ■ Adjust acceleration setting of the relevant axis. ■ Press "RST" button to release the alarm. 		
Code	1426	Message	Inposition error	ROBOT: ① AXIS: ②
Description	allowable position error range is exceeded			Level 1
Cause		Measures		
<ul style="list-style-type: none"> ■ Motor can't satisfy allowable range (IPA) within allowable time (IPE) after completing motion 		<ul style="list-style-type: none"> ■ Press "RST" button to release the alarm. ■ check INPOS related parameter setting value. 		

command (JMOV, etc.) run.

- Increase allowable time (IPE) and allowable range (IPA)
- If the error continuously occurs even after adjusting IPE, IPA, check robot state and adjust GAIN.

Code	1427	Message	TG TimeOut error		
Description	Position command calculation time is exceeded			Level	1
Cause			Measures		
<ul style="list-style-type: none"> ■ Position command calculation time exceeded limited time. 			<ul style="list-style-type: none"> ■ Press "RST" button to release the alarm. 		

Code	1428	Message	TG Mode error		
Description	Trajectory mode conversion violation			Level	1
Cause			Measures		
<ul style="list-style-type: none"> ■ Tried to convert into Parameter Edit Screen in Servo ON maintenance state. 			<ul style="list-style-type: none"> ■ Press "RST" button to release the alarm. ■ convert into Parameter Edit Screen after checking Servo OFF state, 		

Code	1429	Message	ENC Count error	ROBOT: ① AXIS: ②	
Description	Feedback Pulse variation allowable range is exceeded			Level	1
Cause			Measures		
<ul style="list-style-type: none"> ■ Variation of encoder data input from Servo for each regular cycle exceeded allowable range. ■ Multi Turn Clear is conducted. 			<ul style="list-style-type: none"> ■ Press "RST" button to release the alarm. -In case of continuous occurrence, check and replace encoder harness, Servo Board. 		

Code	1430	Message	REF Count error	ROBOT: ① AXIS: ②	
Description	Allowable Reference Pulse variation range is exceeded			Level	1
Cause			Measures		
<ul style="list-style-type: none"> ■ Variation of encoder data input from Servo for each regular cycle exceeded allowable range. ■ If power is not reset after changing axis information in parameter. 			<ul style="list-style-type: none"> ■ Press "RST" button to release the alarm. -In case of continuous occurrence, Check alarm release after turning controller power OFF => ON. 		

Code	1431	Message	Servo ON/OFF TimeOut	ROBOT: ①	
Description	Servo state mismatch			Level	1
Cause			Measures		
<ul style="list-style-type: none"> ■ Number of use axis does not match with number of axis which is in Servo On status ■ Number of use axis does not match with number of axis which is in Servo Off status 			<ul style="list-style-type: none"> ■ Press "RST" button to release the alarm. -In case of continuous occurrence, check motor, Driver and cable 		

■ Emergency

Code	2101	Message	T/P emergency	
Description	T/P emergency		Level	1
Cause		Measures		
<ul style="list-style-type: none"> ■ Emergency switch on T/P is pressed. ■ T/P is connected again to the controller after separating from it. 		<ul style="list-style-type: none"> ■ Turn T/P Emergency switch clockwise to release Emergency state and then press "RST" button to release alarm situation. ■ If the error occurred when T/P Emergency switch is not pressed, (connection state error) T/P ⇔ Tighten Connector Screws to connect the controller to remove shaking of T/P connector. (T/P ⇔ controller contact error) 		
Code	2102	Message	Front emergency	
Description	Front emergency		Level	1
Cause		Measures		
<ul style="list-style-type: none"> ■ Press Front Emergency switch of the controller. 		<ul style="list-style-type: none"> ■ Turn T/P Emergency switch clockwise to release Emergency state and then press "RST" button to release alarm situation. 		
Code	2103	Message	System emergency	
Description	System emergency		Level	1
Cause		Measures		
<ul style="list-style-type: none"> ■ Any of 2NC (normal close, 2 contact) of SYSTEM Emergency part is open on Safety Input Connector on the front of the controller. 		<ul style="list-style-type: none"> ■ Close 2NC (normal close, 2 contact) of SYSTEM Emergency part on Safety Input Connector on the front of the controller and then press "RST" button to release alarm situation (Connect 2NC short connector of SYSTEM Emergency part and check alarm state release.) 		
Code	2104	Message	Auto emergency	
Description	Auto emergency		Level	1
Cause		Measures		
<ul style="list-style-type: none"> ■ Any one 2NC (normal close, 2contact) of AUTO Emergency part of Safety Input Connector on the front of the controller is open. <p>Caution: This occurs only when T/P is in AUTO MODE.</p>		<ul style="list-style-type: none"> ■ Close 2NC (normal close, 2 contact) of AUTO Emergency part on Safety Input Connector on the front of the controller and then press "RST" button to release alarm situation. <p>(Connect 2NC short connector of AUTO Emergency part and check alarm state release.)</p>		
Code	2105	Message	Manual emergency	
Description	Manual emergency		Level	1

Cause		Measures		
<ul style="list-style-type: none"> Any of 2NC (normal close, 2contact) of MANUAL Emergency part on Input Connector on the front of the controller is open. <p>Caution: occurs only when T/P is in MANUAL MODE.</p>		<ul style="list-style-type: none"> Close 2NC (normal close, 2contact) of MANUAL Emergency part on the Safety Input Connector on the front of the controller and then press "RST" button to release alarm situation (Connect 2NC short connector of MANUAL Emergency part and check alarm state release.) 		
Code	2106	Message	Light curtain error	
Description	Light curtain error		Level	1
Cause		Measures		
<ul style="list-style-type: none"> Any of 2NC (normal close, 2 contact) of LIGHT CURTAIN Emergency part on Safety Input Connector on the front of the controller is open. 		<ul style="list-style-type: none"> Close 2NC (normal close, 2 contact) of LIGHT CURTAIN Emergency part on Safety Input Connector on the front of the controller and press "RST" button to release alarm situation (Connect 2NC short connector of LIGHT CURTAIN Emergency part and check alarm state release.) 		
Code	2107	Message	Light curtain2 error	
Description	Light curtain error		Level	1
Cause		Measures		
<ul style="list-style-type: none"> Any of 2NC (normal close, 2contact) of LIGHT CURTAIN Emergency part on the Safety Input Connector on the front of the controller is open. 		<ul style="list-style-type: none"> Close 2NC (normal close, 2 contact) of LIGHT CURTAIN Emergency part on Safety Input Connector on the front of the controller and press "RST" button to release alarm situation (Connect 2NC short connector of LIGHT CURTAIN Emergency part and check alarm state release.) 		
Code	2108	Message	Mode mismatch error	
Description	mismatch of the front Mode switch (Auto/Manual) of the controller		Level	1
Cause		Measures		
<ul style="list-style-type: none"> Mode switch on the front of the controller does not match with contact of T/P mode switch. 		<ul style="list-style-type: none"> Match controller mode. Press "RST" button to release the alarm. 		
Code	2109	Message	Index mode error	
Description	Index Mode (Auto/Manual) mismatch		Level	1
Cause		Measures		
<ul style="list-style-type: none"> Mode input through Index Mode NC/NO does not match with controller mode. 		<ul style="list-style-type: none"> Match Index Mode with controller mode. Press "RST" button to release the alarm. 		
Code	2110	Message	External emergency	
Description	External emergency		Level	1
Cause		Measures		

■ Emergency stop state occurred by F/W or JOB program command in occurrence of controller alarm, Limit IO, Safety IO input situation.

■ Press "RST" button to release the alarm.



■ Servo Driver

Code	4011	Message	Control PS undervolt	ROBOT: ① AXIS: ②
Description	control under voltage protection			Level 1
Cause		Measures		
<ul style="list-style-type: none"> ■ Voltage between P-N of the converter of the power supply dropped below the designated value. ■ Momentary power failure occurred. ■ Lack of power capacity. 		<ul style="list-style-type: none"> ■ Press "RST" button to release the alarm. ■ Remove the cause of control power drop and then input power <ul style="list-style-type: none"> - Measure voltage between L1C-L2C 		
Code	4012	Message	Over-voltage	ROBOT: ① AXIS: ②
Description	overvoltage protection			Level 1
Cause		Measures		
<ul style="list-style-type: none"> ■ Voltage between P-N of the power supply converter exceeded designated value. ■ Power voltage exceeded allowable input voltage. ■ Disconnection of regenerative resistor or external-mounting regenerative resistor is improper and absorbs regenerative energy. 		<ul style="list-style-type: none"> ■ Press "RST" button to release the alarm. ■ Remove cause of voltage rise and then input power. <ul style="list-style-type: none"> - Measure voltage between L1, L2 and L3 - Measure resistance of regenerative resistor connected between Amp terminal P and B. If value is ∞, replace the regenerative resistor. 		
Code	4013	Message	Main PS under voltage	ROBOT: ① AXIS: ②
Description	main under voltage protection			Level 1
Cause		Measures		
<ul style="list-style-type: none"> ■ In case of Pr5.09 (LV travel Selection when main power is OFF) = 1, Pr5.08 (main power OFF detection time) between L1~L3, suddenly stopped than the setting time or voltage between P-N of main power converter dropped below the regulated value during Servo On. ■ Power voltage is low. Momentary power failure occurred. ■ Lack of power capacity 		<ul style="list-style-type: none"> ■ Press "RST" button to release the alarm. ■ Remove cause of voltage drop of electromagnetic contactor of main power and then input power again. <ul style="list-style-type: none"> - Longer setting of Pr5.08 (main power OFF detection time). - Measure voltage between L1, L2 and L3 		
Code	4014	Message	Over-current	ROBOT: ① AXIS: ②
Description	Over current protection, IPM error prevention			Level 2
Cause		Measures		
<ul style="list-style-type: none"> ■ Current flows on the converter exceeded regulated value. ■ Short circuit of motor wire U, V, W ■ Motor wire ground error, contact error ■ Motor damage by fire 		<ul style="list-style-type: none"> ■ Check alarm release after turning controller power OFF => ON ■ Check lead wire of the connector to check for short-circuit of connection U, V, W of motor wire. Correctly connect motor wire. 		

			<ul style="list-style-type: none"> ■ Check insulation resistor between U, V, W of motor wire and ground wire of the motor. In case of poor insulation, replace the motor. ■ Check resistance balance of each line of the motor. In case of imbalance, replace the motor. ■ Check for missing of connector pin on the connecting part U, V, and W of the motor. If loosened or missing, tightly fix it.
--	--	--	---

Code	4015	Message	Over-heat	ROBOT: ① AXIS: ②
Description	overheating protection			Level 2
Cause		Measures		
<ul style="list-style-type: none"> ■ Heat sink or temperature of power device exceeded designated temperature. ■ Ambient temperature exceeded designated temperature. ■ overload 		<ul style="list-style-type: none"> ■ Check alarm release after turning controller power OFF => ON. ■ Improve ambient temperature and cooling condition. ■ Set accel/deceleration time to be longer and lower load. 		

Code	4016	Message	Over-load	ROBOT: ① AXIS: ②
Description	Overload protection			Level 1
Cause		Measures		
<ul style="list-style-type: none"> ■ Torque command value exceeded overload level set to Pr5.12 (overload level setting). ■ Load is large and actual torque started for a long time in exceeding status of rated torque. ■ Oscillation, hunting operation, vibration, abnormal noise of the motor due to gain adjustment error. Inertia ratio Pr0.04 setting error ■ Wiring error, disconnection of the motor ■ operated in brake operating status. 		<ul style="list-style-type: none"> ■ Press "RST" button to release the alarm. (It may take more than 10 seconds for alarm release.) ■ Set accel/deceleration time to be longer. ■ Re-adjust gain. ■ Replace the cable. ■ Measure voltage of the brake terminal. 		

Code	4018	Message	Over-regeneration	ROBOT: ① AXIS: ②
Description	Regenerative overload protection			Level 2
Cause		Measures		
<ul style="list-style-type: none"> ■ Regenerative energy exceeded capacity of the regenerative resistor. 		<ul style="list-style-type: none"> ■ Check alarm release after turning controller power OFF => ON. - If alarm is not released after power re-input, check alarm code marked on 7-Segment of the Driver. If 18.1 are marked, Servo Driver must be replaced. 		

Code	4021	Message	Encoder error	ROBOT: ① AXIS: ②
Description	Encoder communication error protection			Level 2
Cause		Measures		
<ul style="list-style-type: none"> ■ Communication between the encoder and Servo driver stopped more than certain time. ■ Error detected in the data received from the 		<ul style="list-style-type: none"> ■ Check alarm release after turning controller power OFF => ON. ■ If encoder cable and motor cable are bound together, 		

encoder.	separate and check the cable. - measured voltage value of power supplied to the encoder satisfies normal range $DC5V \pm 5\%$ (4.75~5.25V). However, if alarm is continuously not released after re-inputting power, there is possibility of failure.
----------	--

Code	4023	Message	Encoder data error	ROBOT: ① AXIS: ②	
Description	Position deviation excess prevention			Level	2

Cause		Measures		
<ul style="list-style-type: none"> ■ Error detected from the data received from the encoder. 		<ul style="list-style-type: none"> ■ Check alarm release after turning controller power OFF => ON. ■ If encoder cable and motor cable are bound together, separate and check the cable. - Measured voltage value of power supplied to the encoder satisfies normal range $DC5V \pm 5\%$ (4.75~5.25V). However, if alarm is continuously not released after re-inputting power, there is possibility of failure. 		

Code	4024	Message	Position deviation	ROBOT: ① AXIS: ②	
Description	Position deviation excess prevention, velocity deviation excess prevention			Level	1

Cause		Measures		
<ul style="list-style-type: none"> ■ Deviation pulse exceeded setting of Pr0.14. ■ Setting value of Pr0.14 is small ■ Difference between internal position command velocity and actual velocity exceeded setting of Pr6.02. 		<ul style="list-style-type: none"> ■ Press "RST" button to release the alarm. ■ Set Pr0.14, Pr6.02 to bigger value. ■ Check if the motor follows position command pulse. Check if output torque is saturated in the torque monitor. Adjust gain. Set accel/deceleration time to be longer. Lower load and velocity. 		

Code	4025	Message	Hybrid deviation	ROBOT: ① AXIS: ②	
Description	Hybrid deviation excess prevention			Level	2

Cause		Measures		
<ul style="list-style-type: none"> ■ Load position displayed on external scale and motor position displayed on encoder slipped at full close control larger than setting pulse using Pr7B (setting exceeding hybrid deviation). 		<ul style="list-style-type: none"> ■ Check alarm release after turning controller power OFF => ON. ■ Check connection between motor and load. Check connection between external scale and Amp. Check if change of motor position (encoder feedback value) and load position (external scale feedback value) is same mark with that for load move. Check if reversal (Pr3.26) of numerator and denominator (Pr3.24 and Pr3.25) of external scale division and external scale direction are correctly set. 		

Code	4026	Message	Over-velocity error	ROBOT: ① AXIS: ②	
Description	Velocitying prevention			Level	1

Cause		Measures		
-------	--	----------	--	--

- Rotating motor velocity exceeded setting value of Pr5.13.
- Rotating motor velocity exceeded setting value of Pr6.15.

- Press "RST" button to release the alarm.
- Do not execute excessive velocity command. Check command pulse input frequency and division/multiplication ratio. Adjust gain when overshoot occurred due to gain adjustment error.

Code	4027	Message	Absolute clear error	ROBOT: ① AXIS: ②
-------------	-------------	----------------	----------------------	------------------

Description	Command pulse input frequency error prevention, electronic gear error prevention	Level	1
--------------------	--	--------------	----------

Cause		Measures	
<ul style="list-style-type: none"> ■ Frequency of command pulse input exceeded setting of Pr5.32 by 1.2 times. ■ Multiplication and division ratio and electronic gear setting set by number of command pulse per 1 rotation is not proper. 		<ul style="list-style-type: none"> ■ Press "RST" button to release the alarm. ■ Check command pulse input for frequency. ■ Check setting value of the electronic gear. 	

Code	4028	Message	Limit of pulse repla	ROBOT: ① AXIS: ②
-------------	-------------	----------------	----------------------	------------------

Description	Protection of pulse regenerative limit	Level	1
--------------------	--	--------------	----------

Cause		Measures	
<ul style="list-style-type: none"> ■ Output frequency of pulse regenerative exceeded limit. 		<ul style="list-style-type: none"> ■ Press "RST" button to release the alarm. ■ Check setting value of Pr0.11 and Pr5.03. ■ Set Pr5.33 to 0 to inactivate detecting function. 	

Code	4029	Message	Deviation counter	ROBOT: ① AXIS: ②
-------------	-------------	----------------	-------------------	------------------

Description	Prevention of deviation counter overflow	Level	1
--------------------	--	--------------	----------

Cause		Measures	
<ul style="list-style-type: none"> ■ Position deviation based on encoder pulse exceeded 2^{29} (536870912). 		<ul style="list-style-type: none"> ■ Press "RST" button to release the alarm. ■ Check if the motor operates according to position command pulse. ■ Check if output torque saturated in the torque monitor. ■ Adjust gain. 	

Code	4030	Message	Safety detection	ROBOT: ① AXIS: ②
-------------	-------------	----------------	------------------	------------------

Description	Safety input protection	Level	1
--------------------	-------------------------	--------------	----------

Cause		Measures	
<ul style="list-style-type: none"> ■ One or both of input photo coupler of safety input 1 and 2 is in OFF state. 		<ul style="list-style-type: none"> ■ Press "RST" button to release the alarm. ■ Check wiring of safety input 1 and 2 	

Code	4033	Message	Overlaps allocation	ROBOT: ① AXIS: ②
-------------	-------------	----------------	---------------------	------------------

Description	I/F input overlap allocation error prevention	Level	2
--------------------	---	--------------	----------

Cause		Measures	
<ul style="list-style-type: none"> ■ Input signal (SI1~SI10) or Output signal (SO1~SO4) is not correctly allocated 		<ul style="list-style-type: none"> ■ Check alarm release after turning controller power OFF => ON. ■ Allocate correct function to each connector pin 	

Code	4034	Message	Software limit	ROBOT: ① AXIS: ②
Description	prevention of motor operating range setting error			Level 1
Cause		Measures		
<ul style="list-style-type: none"> ■ Motor exceeded designated operating range at Pr5.14 when position command is given within the designated input range. ■ Gain is not appropriate. 		<ul style="list-style-type: none"> ■ Press "RST" button to release the alarm. ■ Check gain and Inertia Ratio. ■ Increase setting value of Pr5.14 or set Pr5.14 to 0 to inactivate protection function. 		
Code	4036	Message	EEPROM para error	ROBOT: ① AXIS: ②
Description	Prevention of EEPROM parameter variable error			Level 3
Cause		Measures		
<ul style="list-style-type: none"> ■ Data of parameter variable save area are damaged while reading data from EEPROM after power ON. 		<ul style="list-style-type: none"> ■ Set all parameter variables again. ■ Check alarm release after turning controller power OFF => ON. ■ If error continues, replace the Amp. 		
Code	4037	Message	EEPROM chk code error	ROBOT: ① AXIS: ②
Description	Prevention of EEPROM check code error			Level 3
Cause		Measures		
<ul style="list-style-type: none"> ■ Data to input to EEPROM are damaged while reading data from EEPROM after power ON. 		<ul style="list-style-type: none"> ■ Replace the Amp. 		
Code	4038	Message	Over-travel inhibit	ROBOT: ① AXIS: ②
Description	Prevention of over-travel inhibition input			Level 2
Cause		Measures		
<ul style="list-style-type: none"> ■ Both of positive and negative over-travel inhibition input (POT/NOT) are ON when Pr5.04, over-travel inhibition input setting = 0. Positive and negative over-travel inhibition input is converted into ON in Pr5.04=0 state. 		<ul style="list-style-type: none"> ■ Check alarm release after turning controller power OFF => ON. ■ Check if increasing time of switch, wire or power supply (DC12~24V) connected to forward/backward over-travel inhibition input is slow. 		
Code	4040	Message	Absolute cnt over	ROBOT: ① AXIS: ②
Description	Protection of absolute system down error			Level 1
Cause		Measures		
<ul style="list-style-type: none"> ■ Supply power of 17bit absolute encoder and battery power is down and voltage of built-in condenser gets down below the regulated value. 		<ul style="list-style-type: none"> ■ Move robot to origin position and connect power for battery and then conduct Multi Turn Clear for absolute encoder. ■ Press "RST" button to release the alarm. - Alarm won't be released before conducting Multi Turn Clear. 		
Code	4041	Message	Safety detection	ROBOT: ① AXIS: ②
Description	Prevention of absolute counter excess error			Level 2
Cause		Measures		

■ Multi Turn counter of 17bit absolute encoder exceeded designated value.

■ Check alarm release after turning controller power OFF => ON.

■ Set Pr0.15 to 2 to ignore Multi Turn counter.

■ Limit moving amount from machine origin within 32,767 rotations.

Code	4042	Message	Absolute over-velocity	ROBOT: ① AXIS: ②
-------------	-------------	----------------	------------------------	------------------

Description	Prevention of absolute velocity error	Level	1
--------------------	---------------------------------------	--------------	----------

Cause	Measures
--------------	-----------------

■ Motor velocity exceeded designated value when only battery power is supplied to 17bit encoder during power failure.

■ Move robot to origin position and connect power for battery and then conduct Multi Turn Clear for absolute encoder.

■ Press "RST" button to release the alarm.

- Alarm won't be released before conducting Multi Turn Clear.

■ Check supply voltage (5V ± 5%) on the encoder side.

■ Check connection state of connector CN X2.

Code	4043	Message	INC-Encoder init err	ROBOT: ① AXIS: ②
-------------	-------------	----------------	----------------------	------------------

Description	Prevention of encoder Initialize error	Level	3
--------------------	--	--------------	----------

Cause	Measures
--------------	-----------------

■ Encoder Initialize error is detected.

■ Replace the motor.

Code	4044	Message	Abs s-turn cnt error	ROBOT: ① AXIS: ②
-------------	-------------	----------------	----------------------	------------------

Description	Prevention of absolute multi Turn counter error	Level	3
--------------------	---	--------------	----------

Cause	Measures
--------------	-----------------

■ 1 rotation counter error of the encoder is detected.

■ Replace the motor.

Code	4045	Message	Abs m-turn cnt error	ROBOT: ① AXIS: ②
-------------	-------------	----------------	----------------------	------------------

Description	Prevention of absolute 1 rotation counter error	Level	3
--------------------	---	--------------	----------

Cause	Measures
--------------	-----------------

■ Error of Multi Turn counter of the encoder is detected.

■ Replace the motor.

Code	4047	Message	Absolute state err	ROBOT: ① AXIS: ②
-------------	-------------	----------------	--------------------	------------------

Description	Prevention of absolute 1 rotation counter error	Level	2
--------------------	---	--------------	----------

Cause	Measures
--------------	-----------------

■ Encoder operates at velocity faster than the designated value after power ON.

■ Check alarm release after turning controller power OFF => ON.

■ Motor is located not to be operated when power is ON.

Code	4048	Message	INC-Encoder Z-phase	ROBOT: ① AXIS: ②
-------------	-------------	----------------	---------------------	------------------

Description	Prevention of encoder Z PHASE error	Level	3
--------------------	-------------------------------------	--------------	----------

Cause		Measures		
<ul style="list-style-type: none"> ■ Z PHASE pulse of incremental series encoder is not detected. The encoder maybe failed. 		<ul style="list-style-type: none"> ■ Replace the motor. 		
Code	4049	Message	INC-Encoder CS signal ROBOT: (a) AXIS: (b)	
Description	Prevention of encoder CS signal error		Level	3
Cause		Measures		
<ul style="list-style-type: none"> ■ Logical CS signal error of incremental series encoder is detected. The encoder maybe failed. 		<ul style="list-style-type: none"> ■ Replace the motor. 		
Code	4050	Message	Ext-scale connection ROBOT: (a) AXIS: (b)	
Description	Prevention of feedback scale wiring error		Level	2
Cause		Measures		
<ul style="list-style-type: none"> ■ Communication between external scale and Amp stopped at certain time and separation detection function is triggered. ■ Communication error at data received from external scale occurred. Most of data error is due to noise. External scale cable is connected, but communication data error occurred. 		<ul style="list-style-type: none"> ■ Connect wiring of external scale according to wiring diagram. Correctly connect connector pin which is incorrectly wired. ■ Secure power supply for DC5V ± 5% (4.75V~5.25V) of external scale. Especially, be cautious if external scale cable is long. ■ If external scale cable and motor cable are bound together, separate the two cables from each other. ■ Connect shield device to FG. 		
Code	4051	Message	Ext-scale comm error ROBOT: (a) AXIS: (b)	
Description	Prevention of external scale state error		Level	2
Cause		Measures		
<ul style="list-style-type: none"> ■ External scale error code is detected. 		<ul style="list-style-type: none"> ■ Check specification of external scale. ■ Clear external scale error. ■ Check alarm release after turning controller power OFF => ON. 		
Code	4055	Message	A-phase connection ROBOT: (a) AXIS: (b)	
Description	Prevention of external scale A, B, Z PHASE wiring error		Level	2
Cause		Measures		
<ul style="list-style-type: none"> ■ Error of A, B and Z phase wiring of external scale (Ex: disconnection). 		<ul style="list-style-type: none"> ■ Check wiring connection of A, B AND Z PHASE. ■ Check alarm release after turning controller power OFF => ON. 		
Code	4080	Message	ESM request error ROBOT: (a) AXIS: (b)	
Description	ESM request error		Level	1
Cause		Measures		
<ul style="list-style-type: none"> ■ EtherCAT communication state error occurred. 		<ul style="list-style-type: none"> ■ Press "RST" button to release the alarm. If alarm won't be released, turn OFF the controller and then 		

		back it ON.	
Code	4081	Message	Synchronization err ROBOT: ① AXIS: ②
Description	Synchronization err		Level 1
Cause		Measures	
<ul style="list-style-type: none"> ■ EtherCAT communication state error occurred. 		<ul style="list-style-type: none"> ■ Press "RST" button to release the alarm. If alarm won't be released, turn OFF the controller and then back it ON. 	
Code	4084	Message	Synchronous est init ROBOT: ① AXIS: ②
Description	Synchronous est init		Level 2
Cause		Measures	
<ul style="list-style-type: none"> ■ An error occurred during communication, Servo Sync, Initialize procedure. 		<ul style="list-style-type: none"> ■ Check alarm release after turning controller power OFF => ON. 	
Code	4087	Message	Compulsory err input ROBOT: ① AXIS: ②
Description	Protection of forced alarm input		Level 1
Cause		Measures	
<ul style="list-style-type: none"> ■ Forced alarm input (E-STOP) is applied. 		<ul style="list-style-type: none"> ■ Press "RST" button to release the alarm. ■ Check wiring of forced alarm input (E-STOP). 	
Code	4088	Message	Main Power undervolt ROBOT: ① AXIS: ②
Description	Protection of Main Power under voltage		Level 2
Cause		Measures	
<ul style="list-style-type: none"> ■ Controller power is turned OFF during EtherCAT communication or communication is not available. 		<ul style="list-style-type: none"> ■ Check alarm release after turning controller power OFF => ON. 	
Code	4091	Message	Command error ROBOT: ① AXIS: ②
Description	Command error protection		Level 1
Cause		Measures	
<ul style="list-style-type: none"> ■ Control mode is converted in short time less than 2ms. 		<ul style="list-style-type: none"> ■ Press "RST" button to release the alarm. If alarm won't be released, turn OFF the controller and then back it ON. 	
Code	4092	Message	Encoder data recover ROBOT: ① AXIS: ②
Description	protection of Encoder data recover error		Level 2
Cause		Measures	
<ul style="list-style-type: none"> ■ Internal position data is not correctly Initialized in absolute mode for semi-close control. 		<ul style="list-style-type: none"> ■ Check alarm release after turning controller power OFF => ON. ■ Secure power supply for DC5V ± 5% (4.75V~5.25V) of external scale. Especially, be cautious if external scale cable is long. ■ If external scale cable and motor cable are bound together, 	

separate two cables from each other.
Connect shield device to FG.

Code	4093	Message	Para setting error	ROBOT: ① AXIS: ②
Description	Parameter setup error protection			Level 2
Cause		Measures		
<ul style="list-style-type: none"> External scale ratio exceeded range value. 		<ul style="list-style-type: none"> Check alarm release after turning controller power OFF => ON. Range value of external scale ratio is 1/40 ~ 160. 		

Code	4095	Message	Motor auto-recognition	ROBOT: ① AXIS: ②
Description	Prevention of motor auto recognition error			Level 3
Cause		Measures		
<ul style="list-style-type: none"> The motor does not fit with the Amp. 		<ul style="list-style-type: none"> Replace it with a motor suitable with the Amp. 		

Code	4098	Message	Unusual Comm IC init	ROBOT: ① AXIS: ②
Description	protection of Unusual communication IC initialization			Level 2
Cause		Measures		
<ul style="list-style-type: none"> Communication IC Initialize procedure is abnormally conducted. 		<ul style="list-style-type: none"> Check alarm release after turning controller power OFF => ON. If the error continuously occurs, replace motor and Servo Amp. 		



■ EtherCAT

Code	4501	Message	EtherCAT stop	
Description	EtherCAT stop		Level	2
Cause		Measures		
<p>■ Task for EtherCAT communication is stopped.</p>		<p>■ Check alarm release after turning controller power OFF => ON.</p> <p>- In case of continuous occurrence,</p> <ol style="list-style-type: none"> 1. Check LAN cable connected to Mainboard and Driver. 2. check if XML file Selection is proper 		

Code	4502	Message	EtherCAT Comm fail	
Description	EtherCAT Comm fail		Level	1
Cause		Measures		
<p>■ Communication alarm in reading procedure for Driver state occurred.</p>		<p>■ Press "RST" button to release the alarm.</p> <p>- In case of continuous occurrence,</p> <ol style="list-style-type: none"> 1. Check LAN cable connected to Mainboard and Driver. <p>■ Press "RST" button to release the alarm. If the error is not solved, check alarm release after turning controller power OFF => ON.</p>		



➤ **Revision**

Date	Revision Detail
Jan 2016	Initial distribution

Robostar

RCQ ROBOT CONTROLLER (Revision)

CONTROLLER MANUAL

FIRST EDITION FEBRUARY 2016

ROBOSTAR CO, LTD
ROBOT R&D CENTER



TECHNICAL DOCUMENT

ROBOSTAR CO, LTD
ROBOT R&D CENTER
